


**Audi > C6 > 2005-2007****6-cylinder Gasoline direct injection 3.2L 4V Engine Mechanical engine code BKH****19 - Removal and Installation**

.

**Engine Coolant Temperature Sensor****Removing**

- Drain coolant ⇒ [Cooling System, Draining and Filling](#) .



- Remove front engine cover - **arrows** - .

- Disconnect electrical connector - **2** - on Engine Coolant Temperature (ECT) sensor G62 .

- Remove retaining clip - **1** - and Engine Coolant Temperature (ECT) sensor G62 .

## Installing

Installation is in reverse order of removal, noting the following:

### Note:

- ◆ *Replace O-ring.*
- Fill with coolant ⇒ [Filling](#) .

*Copyright © 2008 Audi of America, Inc. and Bentley Publishers. All rights reserved. Last processed:*