

- it is necessary. Always follow traffic laws regarding maintaining a safe distance between your vehicle and vehicles ahead.
- pre sense front works within certain limits and cannot react to situations that are outside of the system limits, such as when approaching a stationary vehicle or a stationary obstacle (the end of a traffic jam or a vehicle that has broken down).
 - Always keep in mind that the radar sensor for pre sense front only works within defined detection zones, which means other vehicles may not always be detected correctly.
 - The function and range of the radar sensor can be impaired by rain, snow and heavy mist. Vehicles ahead may not be detected right away, or not detected at all.
 - Reflective surfaces such as guard rails or entrances to tunnels may impair the function of the radar sensor.

Note

The sensor can be displaced by impacts or damage to the bumper, wheel housing and underbody. The pre sense front sensor can be damaged by this. Have your authorized Audi dealer or authorized service facility check their function.

Tips

- You can cancel the braking with increasing force that is initiated by the system by braking yourself, by accelerating noticeably or by swerving.
- For information on driver messages about pre sense, refer to ⇒ page 96.
- Keep in mind that pre sense can brake unexpectedly. Always secure any cargo or objects that you are transporting to reduce the risk of damage or injury.
- Certain pre sense front functions switch off when ESC is switched off (sport mode) or when driving in reverse.
- The pre sense front functions are not available if there is a malfunction in the

adaptive cruise control* system

⇒ page 92 or ⇒ page 96.

- Keep in mind that pre sense front can brake abruptly. Always secure cargo or objects that you transport to reduce the risk of damage or injury.

Settings in the Infotainment system

Applies to vehicles: with Audi pre sense front or Audi adaptive cruise control

- ▶ Select in the MMI: **MENU** button > **Car** > **Systems*** control button > **Driver assistance** > **Audi pre sense**.

Switching the system on and off

Audi pre sense (**System**): If the system is switched off, it switches on again automatically once the ignition is switched on again.

System - Switch Audi pre sense **on-off**. With this, you can switch the prewarning and the braking intervention from Audi pre sense on or off.

Prewarning - The distance and approach warnings can be switched **on/off**.

Tips

- If you restrict or switch off the ESC, the pre sense also switches itself off
⇒ page 190.
- Switch the pre sense off when you are loading the vehicle onto a vehicle carrier, train, ship or other type of transportation. This can prevent undesired warnings from the pre sense system.

Driver messages

Applies to vehicles: with Audi pre sense or Audi adaptive cruise control

Audi pre sense currently unavailable. No sensor vision

This message appears if the sensor view is obstructed, for example by leaves, snow, heavy spray or dirt. Clean the sensor ⇒ page 86, fig. 75.

Audi pre sense: off ▶